

**Hoval Max-3**  
**Oil/gas boiler**

*Boiler*

- 3-pass steel boiler according to EN 303 part 1 and 2 and EN 304 for firing of Diesel oil, oil L and gas.
- Max-3 (420-1250) complies with the Pressure Equipment Directive 2014/68/CE
- Boiler completely welded
- For LowNOx burner with intern flue gas recirculation
- Insulation at the boiler body 80 mm mineral wool mat
- Boiler completely cased with steel plate, red powder coated
- Flue gas outlet to the rear
- Heating flow connection to the top, heating return connections to the rear, incl. counter flanges, screws and seals

*Optional*

- Boiler control panel with boiler controller and heating control in various versions
  - Boiler controller
    - with TopTronic® E control
    - with thermostat T 2.2
    - with thermostat T 0.2
- Free-standing calorifier see Calorifiers
- Boiler door swivels to the left

*Delivery*

- Boiler, thermal insulation and casing delivered separately packed

*On site*

- Mounting of insulation and casing



**Model range**

Max-3 type	Max. - min. output kW
(420)	200-500
(530)	220-610
(620)	240-720
(750)	280-870
(1000)	350-1150
(1250)	480-1350
(1500)	640-1750
(1800)	750-2150
(2200)	920-2500
(2700)	1030-3000

## Boiler controller with TopTronic® E/E13.4 control

- Maximum operating temperature 90 °C

### TopTronic® E controller

#### Control panel

- Colour touchscreen 4.3 inch
- Heat generator blocking switch for interrupting operation
- Fault signalling lamp

#### TopTronic® E control module

- Simple, intuitive operating concept
- Display of the most important operating statuses
- Configurable start screen
- Operating mode selection
- Configurable day and week programmes
- Operation of all connected Hoval CAN bus modules
- Commissioning wizard
- Service and maintenance function
- Fault message management
- Analysis function
- Weather display (with HovalConnect option)
- Adaptation of the heating strategy based on the weather forecast (with HovalConnect option)

#### TopTronic® E basic module heat generator TTE-WEZ

- Control functions integrated for
  - 1 heating/cooling circuit with mixer
  - 1 heating/cooling circuit without mixer
  - 1 hot water charging circuit
  - bivalent and cascade management
- Outdoor sensor
- Immersion sensor (calorifier sensor)
- Contact sensor (flow temperature sensor)
- RAST 5 basic plug set

The supplementary plug set must be ordered in order to use expanded controller functions.

#### Options for TopTronic® E controller

- Can be expanded by max. 1 module expansion:
  - module expansion heating circuit or
  - module expansion heat balancing or
  - module expansion Universal
- Can be networked with a total of up to 16 controller modules:
  - heating circuit/hot water module
  - solar module
  - buffer module
  - measuring module

Number of modules that can be additionally installed in the electrical box:

- 1 module expansion and 2 controller modules **or**
- 1 controller module and 2 module expansions **or**
- 3 controller modules

#### Notice

Max. 1 module expansion can be connected to the basic module heat generator TTE-WEZ!

#### Further information about the TopTronic® E see "Controls"

#### Oil automatic function device OFA

- Control function integrated for
  - flue gas sensor for safety shut-off
  - 0-10 V output for connecting a modulating main pump (incl. ΔT control with low consumption)
  - Standard plug connection for 2-stage burner 1 x 230 V
  - Variable input for plant-specific functions (heat generator block, return sensor, info sensor etc.)
  - Variable output for plant-specific functions (thermostat function, operating message, etc.)

#### Delivery

- Boiler controller separately delivered

#### On site

- Mounting of the boiler controller at the boiler left or right side

## Boiler controller with TopTronic® E/E13.5 control

- Maximum operating temperature 105 °C

- Configuration as TopTronic® E/E13.4 but: safety temperature limiter 120 °C

#### Delivery

- Boiler controller separately delivered

#### On site

- Mounting of the boiler controller at the boiler left or right side

## Control panel with thermostat T 2.2

- Maximum operating temperature 90 °C

- For systems without TopTronic® E control
- For direct 2-stage burner control, requirement starting from external calorifier or heater instruction is possible.
- Main switch "I/O"
- Safety temperature limiter 110 °C
- Selector switch burner load
- Switch summer/winter
- 3 boiler temperature regulators 30-90 °C
  - temperature regulator for base load heating
  - temperature regulator for full load heating
  - temperature regulator for calorifier
- Boiler and burner breakdown lamp
- Plug connection for burner (with cable and plug)

#### Optional

- 2 running time meters integrated
- 2 burner running time meters and pulse counters integrated
- Flue gas thermometer, 4.5 m capillary tube

#### Delivery

- Boiler controller separately delivered

#### On site

- Mounting of the boiler controller at the boiler left or right side

## Control panel with thermostat T 0.2

- Maximum operating temperature 105 °C

- For external control
- For systems without TopTronic® E control
- For special control function

- Main switch "I/O"
- Safety temperature limiter 120 °C
- 3 boiler temperature regulators 50-105 °C
  - temperature regulator for base load heating
  - temperature regulator for full load heating
  - temperature regulator for calorifier
- without burner plug connection

#### Optional

- 2 running time meters integrated
- 2 burner running time meters and pulse counters integrated
- Flue gas thermometer, 4.5 m capillary tube
- Safety temperature limiter 130 °C

#### Delivery

- Boiler controller separately delivered

#### On site

- Mounting of the boiler controller at the boiler left or right side

Oil/gas boiler



**Hoval Max-3 (420-2700)**  
3-pass boiler made of steel for oil/gas  
LowNOx firing, without control panel.  
For operating temperature up to 105 °C

Execution: complete delivery  
Boiler, thermal insulation and casing  
delivered separately packed.

**Permission Boiler**  
CE product ID No. CE-0085BL0015  
according to Directive on appliances burning  
gaseous fuels 90/396/EG

**Pressure Equipment Directive 2014/68/CE**

Max-3 type	Max. - min. output kW	Operating pressure bar
(420)	200-500	6
(530)	220-610	6
(620)	240-720	6
(750)	280-870	6
(1000)	350-1150	6
(1250)	480-1350	6
(1500)	650-1750	6
(1800)	750-2150	6
(2200)	920-2500	6
(2700)	1030-3000	6

Part No.

7013 765
7013 766
7013 773
7013 774
7013 781
7013 782
7013 536
7013 537
7013 538
7013 620

Control panel  
with thermostat



Control panel T 2.2

- Operating temperature max. 90 °C
- For systems without TopTronic® E controller.
- For direct 2-stage burner control, incl. plug connection for burner requirement starting from external calorifier or heater instruction is possible.
  - without burner running time meter and pulse counter
  - incl. 2 burner running time meters integrated
  - incl. 2 burner running time meters and pulse counters integrated
- For mounting on heat generator side right (standard) or left (configuration on request). Specify mounting variant in purchase order.

6015 017  
6015 477  
6015 478



Control panel T 0.2

- Operating temperature max. 105 °C
- For external switching command
- For systems without TopTronic® E controller.
- For special control function without burner plug connection
  - without burner running time meter and pulse counter
  - incl. 2 burner running time meters integrated
  - incl. 2 burner running time meters and pulse counters integrated
- For mounting on heat generator side right (standard) or left (configuration on request). Specify mounting variant in purchase order.

6015 016  
6015 475  
6015 476

Accessories to control panel  
with thermostat

Flue gas thermometer  
4.5 m, capillary tube

241 149

## Boiler controller with TopTronic® E control



### Boiler control E13.4 TopTronic® E

for mounting on heat generator side right (standard) or left (configuration on request). Specify mounting variant in purchase order.  
Operating temperature: max. 90 °C.  
Control function integrated for  
- 1 heating circuit with mixer  
- 1 heating circuit without mixer  
- 1 DHW charging circuit  
Heat generator management  
Additional heat generator management  
Cascade management  
Optionally expandable by max. 1 module expansion:  
- Module expansion heating circuit or  
- Module expansion Universal  
Optionally networkable with up to 16 controller modules (incl. solar module).  
Max. 3 additional controller modules can be installed in control box.

Consisting of:  
electrical box,  
control panel,  
TopTronic® E control module,  
TopTronic® E basic module heat generator,  
oil automatic function device OFA-200,  
safety temperature limiter,  
burner cable cpl. 2-stage, L = 5.0 m,  
1 outdoor sensor AF/2P/K,  
1 immersion sensor TF/2P/5/6T/S1,  
L = 5.0 m  
1 contact sensor ALF/2P/4/T/S1,  
L = 4.0 m

#### Notice

The electrical connection for each external burner must be clarified separately.



### Boiler controller E13.5 TopTronic® E

for installation on the right (standard installation) or left side (configuration on request) of the heat generator. Specify installation variant in purchase order.  
Max. operating temperature: 105 °C.  
Version as boiler controller E13.4  
TopTronic® E

#### Notice

The electrical connection for each external burner must be clarified separately.




## Part No.

6040 236

6040 237

## TopTronic® E module expansions

for TopTronic® E basic module heat generator



### TopTronic® E module expansion heating circuit TTE-FE HK

Expansion to the inputs and outputs of the basic module heat generator or the heating circuit/domestic hot water module for implementing the following functions:

- 1 heating/cooling circuit w/o mixer or
- 1 heating/cooling circuit with mixer

Consisting of:

- Fitting accessories
- 1 contact sensor

ALF/2P/4/T, L = 4.0 m

- Basic plug set FE module

#### Notice

The supplementary plug set may have to be ordered to implement functions differing from the standard!

### TopTronic® E module expansion heating circuit incl. energy balancing

TTE-FE HK-EBZ

Expansion to the inputs and outputs of the basic module heat generator or the heating circuit/domestic hot water module for implementing the following functions:

- 1 heating/cooling circuit w/o mixer or
- 1 heating/cooling circuit with mixer incl. energy balancing in each case

Consisting of:

- Fitting accessories
- 3 contact sensors

ALF/2P/4/T, L = 4.0 m

- Plug set FE module

#### Notice

Suitable flow rate sensors (pulse sensors) must be provided on site.

### TopTronic® E module expansion Universal TTE-FE UNI

Expansion to the inputs and outputs of a controller module (basic module heat generator, heating circuit/domestic hot water module, solar module, buffer module) for implementing various functions

Consisting of:

- Fitting accessories
- Plug set FE module

#### Further information

see "Controls" - "Hoval TopTronic® E module expansions" chapter

#### Notice

Refer to the Hoval System Technology to find which functions and hydraulic arrangements can be implemented.

## Part No.

6034 576

6037 062


6034 575

## Accessories for TopTronic® E



### TopTronic® E controller modules

TTE-HK/WW	TopTronic® E heating circuit/ hot water module	6034 571
TTE-SOL	TopTronic® E solar module	6037 058
TTE-PS	TopTronic® E buffer module	6037 057
TTE-MWA	TopTronic® E measuring module	6034 574



### Supplementary plug set

for basic module heat generator TTE-WEZ	6034 499
for controller modules and module expansion	6034 503
TTE-FE HK	



### TopTronic® E room control modules

TTE-RBM	TopTronic® E room control modules	
	easy white	6037 071
	comfort white	6037 069
	comfort black	6037 070



### Enhanced language package TopTronic® E

one SD card required per control module	6039 253
Consisting of the following languages:	
HU, CS, SL, RO, PL, TR, ES, HR,	
SR, JA, DA	



### HovalConnect

HovalConnect LAN	6049 496
HovalConnect WLAN	6049 498
HovalConnect Modbus	6049 501
HovalConnect KNX	6049 593

### TopTronic® E interface modules

GLT module 0-10 V	6034 578
-------------------	----------



### TopTronic® E sensors

AF/2P/K	Outdoor sensor	2055 889
	H x W x D = 80 x 50 x 28 mm	
TF/2P/5/6T	Immersion sensor, L = 5.0 m	2055 888
ALF/2P/4/T	Contact sensor, L = 4.0 m	2056 775
TF/1.1P/2.5S/6T	Collector sensor, L = 2.5 m	2056 776



### Bivalent switch

for various release or switching functions	
Bivalent switch 1-piece	2056 858
Bivalent switch 2-piece	2061 826



### System housing

System housing 182 mm	6038 551
System housing 254 mm	6038 552



### TopTronic® E wall casing

WG-190	Wall casing small	6052 983
WG-360	Wall casing medium	6052 984
WG-360 BM	Wall casing medium with control module cut-out	6052 985
WG-510	Wall casing large	6052 986
WG-510 BM	Wall casing large with control module cut-out	6052 987

**Further information**  
see "Controls"

Accessories

Part No.



**Flow temperature guard**  
for underfloor heating system (per heating circuit 1 guard) 15-95 °C, switching difference 6 K, capillary tube max. 700 mm, setting (visible from the outside) inside the housing cover.

*Clamp-on thermostat RAK-TW1000.S*  
Thermostat with strap, without cable and plug

242 902



*Immersion thermostat RAK-TW1000.S SB 150*  
Thermostat with pocket 1/2"  
- depth of immersion 150 mm,  
brass nickel-plated

6010 082



**Vibration elements for boiler socket**  
For sound and vibration absorption.  
Made of rubber. Cross section 80/50 mm.

**Delivery**  
4 vibration elements per boiler,  
mounted under the boiler socket

to Max-3 type	Set of pieces	Length mm
(420,530)	4	200
(620,750)	4	400
(1000,1250)	4	500
(1500,1800)	4	800
(2200,2700)	6	800

6003 739  
6003 741  
6003 742  
6005 623  
6005 624



**Blind flange**  
made of steel incl. setscrews and gasket to  
Max-3 (420,530)  
Max-3 (620,750)  
Max-3 (1000-2700)

6002 192  
6030 026  
6002 156



**Intermediate flange drilled to match burner**  
made of steel incl. setscrews and gasket to  
Max-3 (420,530)  
Max-3 (620,750)  
Max-3 (1000-2700)

6017 595  
6017 593  
6017 594

Service



Commissioning

Commissioning by works service or Hoval trained authorised serviceman/company is condition for warranty.

For commissioning and other services please contact your Hoval sales office.



## Max-3 (420-1250)

Type		(420)	(530)	(620)	(750)	(1000)	(1250)
• Nominal output at 80/60 °C <sup>1)</sup>	kW	500	610	720	870	1150	1350
• Max. - min. output (Heating oil EL, variant 1 and natural gas H, variant 1)	kW	320-500	350-610	450-720	520-870	680-1150	850-1350
• Max. - min. output (natural gas H, variant 2)	kW	200-500	220-610	240-720	280-870	350-1150	480-1350
• Burner input max.	kW	453	575	672	813	1085	1351
• Dimensions		see Dimensions					
• Boiler operating temperature max. <sup>2)</sup>	°C	90	90	90	90	90	90
• Boiler operating temperature min.		see table operating conditions (below)					
• Return flow temperature min.		see table operating conditions (below)					
• Flue gas temperature min. at the boiler		see table operating conditions (below)					
• Safety temperature limiter setting (water side) <sup>3)</sup>	°C	110	110	110	110	110	110
• Operating pressure	bar	6	6	6	6	6	6
• Boiler efficiency at 80/60 °C in full-load operation (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	92.7/87.5	92.4/87.2	92.4/87.2	92.5/87.3	92.5/87.3	92.5/87.3
• Boiler efficiency at 30 % partial load (EN 303) (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	95.2/89.8	95.3/89.9	94.9/89.5	95.2/89.8	95.3/89.9	95.2/89.8
• Nominal efficiency at 75/60 °C (DIN 4702-8) (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	94.8/89.5	94.7/89.4	94.3/89.0	94.8/89.4	94.9/89.5	94.8/89.4
• Stand-by loss qB at 70 °C	Watt	1000	1035	1120	1180	1250	1380
• Flue gas resistance at nominal output 180 °C flue gas temperature, 12.5 % CO <sub>2</sub> , 500 m over sea level (tolerance ± 20 %)	mbar	4.9	5.7	5.2	6.5	7.4	8.0
• Flue gas mass flow at nominal output 12.5 % CO <sub>2</sub> heating oil	kg/h	850	1037	1224	1479	1955	2295
• Flow resistance boiler <sup>4)</sup>	z-value	0.022	0.022	0.008	0.008	0.003	0.003
• Water flow resistance at 10 K	mbar	40.4	60.1	30.5	44.5	29.1	40.2
• Water flow resistance at 20 K	mbar	10.1	15.1	7.6	11.1	7.3	10
• Water flow volume at 10 K	m <sup>3</sup> /h	42.8	52.2	61.7	74.5	98.5	115.7
• Water flow volume at 20 K	m <sup>3</sup> /h	21.4	26.1	30.8	37.2	49.2	57.9
• Boiler water content	litres	552	520	969	938	1528	1478
• Boiler gas volume	m <sup>3</sup>	0.583	0.602	0.846	0.872	1.35	1.39
• Insulation thickness boiler body	mm	80	80	80	80	80	80
• Weight (incl. casing)	kg	1093	1150	1770	1800	2500	2600
• Weight (without casing)	kg	943	1000	1590	1620	2360	2460
• Maximum draught/underpressure at flue gas outlet	Pa	-50	-50	-50	-50	-50	-50
• Combustion chamber dimension Ø inside x length	mm	606x1624	606x1624	684x1899	684x1899	782x2182	782x2182
• Combustion chamber volume	m <sup>3</sup>	0.466	0.466	0.669	0.669	1.047	1.047

<sup>1)</sup> At nominal output, the pollutant limit values and flue gas losses as per regulation LRV 92 (CH) are complied with.

<sup>2)</sup> Limited by the boiler controller E13.4 TopTronic® E and T 2.2 to 90 °C or by E13.5 TopTronic® E and T 0.2 to 105 °C.

<sup>3)</sup> Max. safety temperature for boiler controller E13.4 TopTronic® E and T 2.2: 110 °C or E13.5 TopTronic® E and T 0.2: 120 °C.

<sup>4)</sup> Flow resistance boiler in mbar = flow rate (m<sup>3</sup>/h)<sup>2</sup> x z

### Possible operating conditions:

Fuel		Heating oil EL		Natural gas H, low-sulphur heating oil EL		Heating oil L
		Variant 1	Variant 2	Variant 1	Variant 2	
min. flue gas temperature	°C	130	110	130	100	130
min. boiler temperature	°C	60	65	65	75	65
min. return temperature	°C	50	55	55	65	55
Return temperature control		yes	yes	yes	yes	yes

## Max-3 (1500-2700)

Type		(1500)	(1800)	(2200)	(2700)
• Nominal output at 80/60 °C <sup>1)</sup>	kW	1750	2150	2500	3000
• Max. - min. output (Heating oil EL, variant 1 and natural gas H, variant 1)	kW	1050-1750	1250-2150	1500-2500	1780-3000
• Max. - min. output (natural gas H, variant 2)	kW	640-1750	750-2150	920-2500	1030-3000
• Burner input max.	kW	1610	1930	2360	2896
• Dimensions		see Dimensions			
• Boiler operating temperature max. <sup>2)</sup>	°C	90	90	90	90
• Boiler operating temperature min.			see table operating conditions (below)		
• Return flow temperature min.			see table operating conditions (below)		
• Flue gas temperature min. at the boiler			see table operating conditions (below)		
• Safety temperature limiter setting (water side) <sup>3)</sup>	°C	110	110	110	110
• Operating pressure	bar	6	6	6	6
• Boiler efficiency at 80/60 °C in full-load operation (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	92.4/87.2	92.5/87.3	92.5/87.3	92.5/87.3
• Boiler efficiency at 30 % partial load (EN 303) (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	95.2/89.8	95.3/89.2	95.2/89.2	95.2/89.2
• Nominal efficiency at 75/60 °C (DIN 4702-8) (related to net calorific value NCV/gross calorific value GCV, heating oil EL)	%	94.8/89.4	94.9/89.5	94.9/89.5	95/89.5
• Stand-by loss qB at 70 °C	Watt	1850	1950	2100	2300
• Flue gas resistance at nominal output 180 °C flue gas temperature, 12.5 % CO <sub>2</sub> , 500 m over sea level (tolerance ± 20 %)	mbar	7.0	8.8	9.1	8.0
• Flue gas mass flow at nominal output 12.5 % CO <sub>2</sub> heating oil	kg/h	3031	3723	4329	5195
• Flow resistance boiler <sup>4)</sup>	z-value	0.022	0.022	0.002	0.001
• Water flow resistance at 10 K	mbar	45.0	67.9	91.8	132.2
• Water flow resistance at 20 K	mbar	11.3	17	23	33.1
• Water flow volume at 10 K	m <sup>3</sup> /h	150	184.3	214.3	257.1
• Water flow volume at 20 K	m <sup>3</sup> /h	75	92.1	107.1	128.6
• Boiler water content	litres	2343	2750	3050	3550
• Boiler gas volume	m <sup>3</sup>	1.956	2.51	2.761	3.037
• Insulation thickness boiler body	mm	80	80	80	80
• Weight (incl. casing)	kg	3566	4888	5017	5589
• Weight (without casing)	kg	3266	4633	4647	5189
• Maximum draught/underpressure at flue gas outlet	Pa	-50	-50	-50	-50
• Combustion chamber dimension Ø inside x length	mm	880x2417	976x2605	976x2905	976x3233
• Combustion chamber volume	m <sup>3</sup>	1.58	2.07	2.3	2.41

<sup>1)</sup> At nominal output, the pollutant limit values and flue gas losses as per regulation LRV 92 (CH) are complied with.

<sup>2)</sup> Limited by the boiler controller E13.4 TopTronic® E and T 2.2 to 90 °C or by E13.5 TopTronic® E and T 0.2 to 105 °C.


<sup>3)</sup> Max. safety temperature for boiler controller E13.4 TopTronic® E and T 2.2: 110 °C or E13.5 TopTronic® E and T 0.2: 120 °C.

<sup>4)</sup> Flow resistance boiler in mbar = flow rate (m<sup>3</sup>/h)<sup>2</sup> x z

### Possible operating conditions:

Fuel		Heating oil EL		Natural gas H, low-sulphur heating oil EL		Heating oil L
		Variant 1	Variant 2	Variant 1	Variant 2	
min. flue gas temperature	°C	130	110	130	100	130
min. boiler temperature	°C	60	65	65	75	65
min. return temperature	°C	50	55	55	65	55
Return temperature control		yes	yes	yes	yes	yes

## Flue gas output diagram




kW = Boiler output

°C = Flue gas temperature on a clean surface,  
boiler flow temperature 80 °C, return temperature 60 °C (in accordance with DIN 4702).

- Operation with heating oil EL,  
natural gas  
 $\lambda = 1.22$  with max. burner output  
(CO<sub>2</sub> heating oil EL = 12.5 %, CO<sub>2</sub> natural gas = 9.8 %)


- A reduction of the boiler water temperature to 10 K causes a reduction of the flue gas temperature of approx. 6-8 K.  
- A modification of the CO<sub>2</sub> concentration of +1 % causes a modification of the flue gas temperature of approx. -8 K.  
- A modification of the CO<sub>2</sub> concentration of -1 % causes a modification of the flue gas temperature of approx. +8 K.

## Flue gas resistor




### Max-3 (420-1250)

(Dimensions in mm)



### Max-3 (1500-2700)

(Dimensions in mm)




1	Flow	(420,530) (620,750) (1000,1250) (1500-2200) (2700)	DN 100, PN 6 DN 125, PN 6 DN 150, PN 6 DN 150, PN 6 DN 200, PN 6	2	Return	(420,530) (620,750) (1000,1250) (1500-2200) (2700)	DN 100, PN 6 DN 125, PN 6 DN 150, PN 6 DN 150, PN 6 DN 200, PN 6	5	Flue gas collector cleaning opening R 1"
				3	Flue gas outlet			6	Drain R 1½"
				4	Cleaning opening			7	Cable routing
								8	Control panel
								9	Electrical connection
								10	Bushing Rp ¾" with immersion sleeve for boiler temperature sensor

Max-3 type	a	b	c	f	g	h	i	k	l	l1	m	n	Ø o	p	q	r
(420,530)	1060	1190	515	1770	181	1230	950	104	2178	2074	641	100	299	54	34	175
(620,750)	1180	1310	550	2045	181	1350	1050	105	2452	2347	666	95	349	55	35	170
(1000,1250)	1370	1500	635	2330	181	1550	1250	107	2739	2632	681	111	349	77	37	175
(1500)	1560	1610	665	2685	212	1710	1350	103	3040	2940	722	80	447	83	34	65
(1800)	1720	1770	735	3055	214	1870	1460	103	3424	3320	724	80	447	83	52	65
(2200)	1720	1770	735	3355	214	1870	1460	101	3724	3625	724	80	447	81	50	65
(2700)	1750	1800	755	3700	212	1900	1410	82	4032	3950	722	80	647	82	51	65

Max-3 type	s	t	u	v	w	x
(420,530)	350	595	660	1330	450	-
(620,750)	550	722	786	1445	475	-
(1000,1250)	415	620	685	1660	590	-
(1500)	310	777	842	1790	695	1850
(1800)	310	890	952	1950	773	2040
(2200)	310	890	952	1950	773	2340
(2700)	370	917	982	1980	790	2670

### Dimensions without insulation and casing

Boiler incl. hinged flange, connector and flue gas collector.  
(Dimensions in mm)



Max-3 type	a <sup>1)</sup>	b	c	d	e	f	g	h	i	k	l	m	n	o	p
(420,530)	1920	150	1770	277	2222	1060	1180	196	120	1060	1376	2077	175	460	1072
(620,750)	2195	150	2045	228	2498	1180	1300	196	120	1180	1496	2353	172	485	1192
(1000,1250)	2480	150	2330	228	2783	1370	1500	187	120	1380	1660	2638	198	500	1392
(1500)	2685	164	2568	260	3078	1560	1680	162	120	1560	1842	2923	240	510	-
(1800)	3055	166	2760	450	3467	1720	1840	162	120	1720	2002	3325	430	510	-
(2200)	3355	166	3060	450	3767	1720	1840	162	120	1720	2002	3625	430	510	-
(2700)	3700	164	3390	430	4075	1750	1870	169	120	1750	2039	3953	430	510	-

Max-3 type	q	r	s	v	w	x	y
(420,530)	175	350	950	475	990	-	-
(620,750)	170	550	1050	535	1110	-	-
(1000,1250)	175	415	1250	630	1298	-	-
(1500)	65	310	1350	725	1494	1790	153
(1800)	65	310	1460	805	1654	1950	153
(2200)	65	310	1460	805	1654	1950	153
(2700)	65	370	1410	820	1684	1980	153

<sup>1)</sup> Max-3 (1500-2700): socket protrudes


### Required min. width of door and corridor to bring in the boiler

The stated measurements are minimal dimensions

$$K = \frac{B}{T} \times L$$


$$T = \frac{B}{K} \times L$$

T Door width  
K Corridor width  
B Boiler width  
L Max. boiler length




Furnace dimensions



Max-3 (420,530)




Max-3 (620-1250)




Max-3 (1500-2700)




Screw joint flange  
Max-3 (420,530)  
4 x M12 (45°)  
4 x M12 (15°)




Screw joint flange  
Max-3 (620,750)  
6 x M12 (15°)  
  
Screw joint flange  
Max-3 (1000,1250)  
6 x M16 (15°)



Screw joint flange  
Max-3 (1500-2700)  
6 x M16 (15°)



Swinging out of boiler door  
Boiler door is swivelling to the right or left  
(Dimensions in mm)



Dimensions  
(Dimensions in mm)

Max-3 type	A	B	C	D	E	F	G	H	M
(420,530)	290	330	515	250	606	1624	163	30	450
(620,750)	350	400	550	310	684	1899	163	30	600
(1000,1250)	400	450	635	330	782	2182	163	30	600
(1500)	400	450	665	360	880	2417	170	30	600
(1800)	400	450	735	360	976	2605	170	30	600
(2200)	400	450	735	360	976	2905	170	30	600
(2700)	400	450	755	360	976	3233	170	30	600

Max-3 type	a	b
(420,530)	1060	150
(620,750)	1180	150
(1000,1250)	1370	150
(1500)	1520	175
(1800,2200)	1680	175
(2700)	1700	175

## Standards and guidelines

The official regulations for installation and operation must be observed. In particular, these are the country-specific standards (e.g. EN standard, DIN standards, ...) as well as the corresponding regional regulations.

The following requirements and directives must be complied with:

- Hoval technical information and installation instructions
- hydraulic and technical control regulations of Hoval
- DIN EN 12828  
Safety-relevant requirements
- DIN EN 12831 Heaters  
Rules for the calculation of the heat requirements of buildings
- VDI 2035 Protection against damage by corrosion and boiler scale formation in heating and service water installations
- EN 14868 Protection of metallic materials against corrosion
- VDE 0100 supplement 2

## Water quality in heating systems

### Filling and replacement water, heating water

#### The following applies:

- VDI 2035
- In addition, the EN 14868 standard must be applied, **as well as the manufacturer-specific specifications**

### Manufacturer-specific specifications

#### Filling and replacement water

The filling and replacement water can be both fully demineralised and also merely softened.

#### Heating water

- In the case of **full demineralisation of the filling and replacement water**, the electrical conductivity of the heating water must not exceed the value of 100 µS/cm.

- In the case of **softening the filling and replacement water**, the following conditions must be complied with:

The quality of the heating water must be checked and documented periodically:

- For an installed heat output above 100 kW up to and including 1000 kW, an annual check of the heating water is required.
- For an installed heat output above 1000 kW, an check of the heating water is required twice a year.

The following standard values for the heating water must be measured and adhered to:

- Electrical conductivity of the heating water for operation with water containing salts: > 100 µS/cm to ≤ 1500 µS/cm
- pH value of the heating water for systems without aluminium alloy as water-side material 8.2 to 10.0 (measurement 10 weeks after commissioning at the earliest)

- The sum of the chloride, nitrate and sulphate contents in the heating water must not exceed 50 mg/l in total.

#### Additional notices

- Hoval boilers and calorifiers are suitable for heating systems without significant oxygen intake. (System type I according to EN 14868).
- Systems with continual oxygen intake (e.g. underfloor heating without diffusion-proof plastic piping) or intermittent oxygen intake (e.g. requiring frequent topping-up) must be equipped with a system separation.
- If only the boiler is replaced in an existing system, it is not recommended for the entire heating system to be refilled, provided that the heating water already contained in the system complies with the relevant directives or standards.
- Before filling new systems and, where necessary, existing heating systems containing heating water that does not comply with the directives or standards, the heating system must be professionally cleaned and flushed. The boiler must not be filled until the heating system has been flushed.

## Frost protection agent

The planning sheet "Use of frost protection agent" is available from your Hoval contact person.

## Combustion air supply

The combustion air supply must be warranted. The air opening must not be lockable. It is very important to ensure that the combustion air is free from halogen compounds. These are present, for example, in spray cans, varnishes, glues, solvents and cleansing agents.

#### Room air dependent operation:

- Minimum free cross-section for the air opening can be assumed as follows by way of simplification. Nominal heat output is the determining factor!
- A minimum free cross-section of once 150 cm<sup>2</sup> or twice 75 cm<sup>2</sup> and an additional 2 cm<sup>2</sup> for each kW boiler capacity in excess of 50 kW is required for the air opening into the outside air.

## Burner installation

- If the weight of the burner (including attachments) of gas and dual-fuel burners is more than 90 kg and the distance of the centre of gravity of the burner to the boiler door is greater than 60 cm, support the burner housing weight directly with a strut to the boiler room floor.
- Depending on the size of the burner flange, an intermediate flange may be required to attach the burner. The intermediate flange including screws and seal must be supplied by the burner company.
- The lines must be positioned so that the boiler door can still be fully opened.
- To allow the boiler door to be swung out 90° to the left or right, the connections must be flexible and routed to the burner in a sufficiently large loop
- In systems with ThermoCondensor, the burner must additionally absorb the resistance of the heat exchanger

The space between the burner pipe and the hinged flange is to be insulated. A line must be routed from the burner to the sight glass to carry cooling air, in order to cool the boiler sight glass and keep it clean.  
(Delivery by the burner company)



**Electric connection of the burner**

- Control voltage 1 x 230 V
- Burner motor 1 x 230 V / 3 x 400 V.
- The burner must be connected to the burner connection plug of the boiler.
- For safety reasons the electrical cable of the burner must be that short that the plug must be removed when swivelling boiler door.

**Sound absorbing**

Sound absorption is possible through the following steps:

- Heating room walls, ceiling and floor should be very solidly built, a sound absorber should be mounted into the air inlet. Pipe holders and support should be protected by means of anti-vibration sleeves.
- Install sound attenuation cowl for burner.
- If living rooms are located above or under the boiler room, vibration absorbers have to be mounted to the boiler base. Pipes and flue gas tube must be connected flexibly with compensators.
- Connect circulating pumps to the piping network using expansion joints.
- For damping of flame noise it is possible to install a silencer into the flue gas tube (space should be foreseen for later installation).

**Measures for sound reduction**

Make sure right from the planning phase that bedrooms are not situated in the immediate vicinity of the sound source (heating room, chimney).

A reduction of the radiated burner air sound level in the heating room (reduction of the burner noises) of up to approx. 12 dB can be achieved encapsulating the burner (sound attenuation cowl).

A significant part of the noise development in the combustion chamber and in the secondary heating surfaces is radiated as airborne noise via the flue gas line.

In addition, depending on dimensioning of the chimney and intersection, resonance effects caused by the vibration of the combustion noises (amplification) can occur.

These noises can be reduced on the one hand by measures on the burner side, such as modification of the flame geometry, the atomisation characteristic or the fuel throughput.

On the other hand, flue gas silencers achieve an important noise reduction.

These silencers must usually be adapted to low frequencies of 60-250 Hz.

Flue gas silencers work based on the principle of sound absorption.

The kinetic energy of the flue gases is consumed due to friction, which means a draughting requirement increase in the flue gas line is necessary. This must be taken into account when dimensioning the burner.

The connection piece from the boiler to the flue gas silencer must be gas-tight as the draught and pressure zero points lie behind the flue gas silencer.

The space required of approx. 1 m for retrofitting of a flue gas silencer should be provided during planning.


Note also that secondary air devices are installed only behind a flue gas silencer.

**Installation instructions**

Please observe the installation instructions supplied with every boiler.

**Chimney/flue gas system****Flue gas line**

- The flue gas tube between boiler and chimney must be connected with an angle 30-45° to the chimney.



- If the flue gas tube is longer than 1 m, it must be insulated.
- The flue gas tube must be designed that no condensate water can get into the boiler.
- A closeable flue gas measuring socket with an inner diameter of 10-21 mm must be foreseen. The socket has to be led over the thermal insulation.

**Chimney**

- The flue gas system must be humidity-insensitive and acid-proof and admitted for flue gas temperatures up to > 160 °C.
- For existing chimney installation the restoration must be carried out according to the instructions of the chimney constructor.
- Calculation of the profile of the chimney according to DIN 4705.
- It is recommendable to use a secondary air valve for chimney draft limiting.

**Flue gas temperature and power ranges**

In order to achieve a good combustion quality (optimum flame burnout), the outputs must not be less than the specified minimum values.

For new systems, acid-resistant chimneys must be provided or the flue gas temperature must be set correspondingly higher (min. 160 °C).

The minimum flue gas temperature must be coordinated with the chimney conditions, otherwise the formation of sulphuric acid can lead to soot buildup in the chimney.

**Diaphragm pressure expansion tank**

- Ideally, the diaphragm pressure expansion tank should be connected to the heating system as described in our example applications, with a removable or sealable actuation device. This means that it is not necessary to drain the entire system in order to carry out work on the diaphragm pressure expansion tank.

**Safety valve**

- A safety valve and an automatic air vent must be installed in the safety flow.